



NEW!

Rotating Pop-Up Nozzle

Rotating Pop-Up nozzles are installed in the tank or container walls and are used when installation conditions are difficult, for example due to the presence of agitators, manholes and other nozzles. Often, CIP cleaning operations require that the nozzle does not remain in the container during production.

Advantages

- Operated by liquid pressure
- No electrical / pneumatic components required
- Spray angle: 200° (plus additional solid jet)
- Usage in low-pressure applications

Applications

- Efficient cleaning and rinsing of tanks or containers, for example
- Food industry
 - Beverage industry
 - Pharmaceutical industry
 - Chemical industry



Technical data
Ordering data





Lechler GmbH
Precision Nozzles - Nozzle Systems
P.O. Box 13 23
72544 Metzingen / Germany
Phone +49 (0 71 23) 962-0
Telefax +49 (0 71 23) 962-333

E-Mail: info@lechler.de
Internet: www.lechler.com

Rotating Pop-Up Nozzle

- Series 500.382
- Material: Stainless steel 316L
(Stainless steel spring 1.4310, bearing made of PEEK)
- Flow rate water: 7.6 l/min at 1 bar
10.8 l/min at 2 bar
13.2 l/min at 3 bar
- Spray angle: 200°, plus additional 1 solid jet



- Opening pressure: 0.8 bar
- Operating pressure: 1.2 - 2.0 bar
- Cleaning diameter: 1.0 m
- Rinsing diameter: 1.5 m
- Temperature: max. 80° C



Rotating Pop-Up Nozzle

- Series 500.453
- Material: Stainless steel 316L
(Stainless steel spring 1.4310, bearing made of PEEK)
- Flow rate water: 28.3 l/min at 1 bar
40.0 l/min at 2 bar
49.0 l/min at 3 bar
- Spray angle: 200°, plus additional 4 solid jets

- Opening pressure: 0.8 bar
- Operating pressure: 1.2 - 2.0 bar
- Cleaning diameter: 1.5 m
- Rinsing diameter: 2.0 m
- Temperature: max. 80° C



Please note for any type: We do not recommend the operation with compressed air. Higher pressure generally means higher wear and smaller droplets. This might have adverse effects on the cleaning result. In order to protect the bearing a line-strainer with a mesh size of 0.3 mm/50 mesh is recommended.